



Antenna Pattern – 704MHz

704CH




Antenna Pattern – 734MHz

734CH




Antenna Pattern – 756MHz

756CH _____









Antenna Pattern – 768MHz

768CH _____




Antenna Pattern – 787MHz

787CH




Antenna Pattern – 824MHz

824CH _____




Antenna Pattern – 868MHz

868CH




Antenna Pattern – 880MHz

880CH _____




Antenna Pattern – 915MHz

915CH _____




Antenna Pattern – 960MHz

960CH




Antenna Pattern – 1710MHz

1710CH




Antenna Pattern – 1785MHz

1785CH _____




Antenna Pattern – 1805MHz

1805CH _____




Antenna Pattern – 1850MHz

1850CH _____




Antenna Pattern – 1880MHz

1880CH




Antenna Pattern – 1920MHz

1920CH _____




Antenna Pattern – 1990MHz

1990CH_____




Antenna Pattern – 2110MHz

2110CH




Antenna Pattern – 2140MHz

2140CH _____




Antenna Pattern – 2170MHz

2170CH




Antenna Pattern – 2300MHz

2300CH_____




Antenna Pattern – 2400MHz

2400CH




Antenna Pattern – 2500MHz

2500CH _____




Antenna Pattern – 2570MHz

2570CH _____



Antenna Pattern – 2620MHz

2620CH



Antenna Pattern – 2690MHz

2690CH _____

